

ANTIK

SMART

WI-FI WALL PLUG 16A

ATK-SPL1-W16A

INSTRUCTION MANUAL

EN

Read this manual carefully before use, and retain it for future reference.



ANTIK Technology
 Carskeho 10, 04001 Kosice, Slovakia (European Union)
 www.antiktech.com
 Manufactured in P. R. C.

What's in the Box

1. Home Control Outlet x 1
2. User Manual x 1

The Main Option Button

ON/OFF

Turn on/off the plug

Can be used as reset button. Long press to reset
 (make sure you really need to reset)

Parameters

1. Wireless type: WiFi 2.4GHz 802.11b/g/n
2. Humidity: <80%
3. Material: ABS+PC
4. Rated voltage: AC 100-240 V
5. Rated current: 16A (Max)
6. Working Temp: -10°C~40°C

Install the Antik SmartHome APP

1. You can download "Antik SmartHome" app from Apple Appstore, Google Play, or scan the QR code below.
2. Enter the register / log in interface, input the phone number for getting the verification code to register an account.



The free app Antik SmartHome is compatible with mobile devices that support iOS 8.0 above, Android 4.4 above.

Connecting Your Socket with APP

1. Ensure that the socket is connected to the power, then Launch "Antik SmartHome" APP, tap "ADD DEVICES" or "+" at the upper right corner of the page and select "Plug (BLE+Wi-Fi)";
2. Long press on/off button of the device for 5 seconds until indicator light flash quickly, the app in "Add Device" page.
3. Make sure the indicator light is flashing quickly and confirm it in app;
4. Choose the local WiFi and enter the correct password, and confirm;
5. Wait for configuring successfully, then tap "Done"

Getting to Know Antik SmartHome**1. Devices**

You can list device by tap the "Home" Icon. If you want to add a device, please click the "+" icon in the upper right corner.

2. Switch

- A. You can press on/off button to turn on/off power.
- B. When the socket is connected to the network, you can use your smartphone to turn on and off the power.
- C. You can use an intelligent speaker to control the socket
- D. You can create scene to control sockets.

3. Timer

You can set the socket to turn on/off at the time you want.

4. Countdown

Through the countdown function, you can turn on/off the power after the desired time.

5. Electricity statistics

If your device has energy monitoring function, you can view real-time and historical power consumption here.

**6. Scenes**

With this function, you can create your characteristic as you want.

7. Profile

Profile is the entrance for the users to manage personal information, mainly show the following information:



ANTIK

SMART

WI-FI WALL PLUG 16A

ATK-SPL1-W16A

NÁVOD NA POUŽITIE

SK

Pred použitím si tento návod pozorne prečítajte a uschovajte ho pre budúce použitie.



ANTIK Technology
Carskeho 10, 04001 Kosice, Slovakia (European Union)
www.antiktech.com
Manufactured in P. R. C.

Čo je v balení

1. Zásuvka x 1
2. Používateľská príručka x 1

Hlavné tlačidlo

ON/OFF

Zapnutie/vypnutie zásuvky

Môže slúžiť aj ako resetovacie tlačidlo.

Podržaním vykonáte reset (uistite sa, že reset naozaj potrebujete).

Parametre

1. Bezdrôtové pripojenie: WiFi 2.4 GHz 802.11b/g/n
2. Vlhkosť: <80 %
3. Materiál: ABS + PC
4. Menovité napätie: AC 100–240 V
5. Menovitý prúd: 16 A (max.)
6. Prevádzková teplota: –10 °C až 40 °C

Aplikácia Antik SmartHome

1. Aplikáciu Antik SmartHome si môžete stiahnuť z Apple App Store, Google Play alebo naskenovaním QR kódu nižšie.
2. Na obrazovke registrácie/prihlásenia zadajte svoje telefónne číslo, aby ste získali overovací kód a zaregistrovali si účet.



Bezplatná aplikácia Antik SmartHome je kompatibilná s mobilnými zariadeniami, ktoré podporujú iOS 8.0 a vyššie, resp. Android 4.4 a vyššie.

Pripojenie vašej zásuvky k aplikácii

1. Uistite sa, že zásuvka je pripojená k elektrickej sieti, potom spustíte aplikáciu Antik SmartHome. Ťuknite na „PRIDAŤ ZARIADENIE“ alebo na znak „+“ v pravom hornom rohu obrazovky a vyberte Zásuvka (BLE+Wi-Fi).
2. Podržte tlačidlo zapnutia/vypnutia na zariadení po dobu 5 sekúnd, až kým indikátor nezačne rýchlo blikáť, a zostaňte na stránke „Pridať zariadenie“ v aplikácii.
3. Uistite sa, že kontrolka bliká rýchlo, a potvrďte to v aplikácii.
4. Vyberte lokálnu Wi-Fi sieť, zadajte správne heslo a potvrďte.
5. Počkajte, kým sa konfigurácia úspešne dokončí, potom ťuknite na „Hotovo“.

Zoznámenie sa s Antik SmartHome**1. Zariadenia**

Zariadenia si môžete zobrazit' ťuknutím na ikonu Domov (Home). Ak chcete pridať nové zariadenie, kliknite na ikonu + v pravom hornom rohu.

2. Prepínač (Switch)

- A. Tlačidlom zapnutia/vypnutia môžete manuálne zapnúť alebo vypnúť zásuvku.
- B. Keď je zásuvka pripojená k sieti, môžete ju zapínať a vypínať cez smartfón.
- C. Zásuvku môžete ovládať aj pomocou inteligentného reproduktora.
- D. Môžete si vytvoriť scény na ovládanie zásuviek.

3. Časovač (Timer)

Môžete nastaviť, aby sa zásuvka zapínala alebo vypínala v požadovaný čas.

4. Odpočítavanie (Countdown)

Vďaka funkcii odpočítavania môžete zapnúť alebo vypnúť zásuvku po uplynutí nastaveného času.

5. Štatistiky spotreby elektriny

Ak vaše zariadenie podporuje funkciu monitorovania energie, môžete tu sledovať aktuálnu aj historickú spotrebu elektrickej energie.

**6. Scény**

Pomocou tejto funkcie si môžete vytvoriť vlastné scény podľa svojich predstáv.

7. Profil

Profil je miesto, kde používatelia spravujú svoje osobné informácie. Hlavne obsahuje nasledujúce údaje:

